


Required components for installation:

- Ethernet cable
- Network with DHCP capable router
- Browser (PC / Mac) or trivum App
- RCA connectors for Line In and/or Line Out
- Speakers with 4 or 8 Ohms impedance

Quick Installation Guide



Technical Data

Zones	4 Zone Expandable to up to 64 zones
Source	4x Streaming Clients
Streaming	up to 192kHz 24Bit
Music Formats	MP3, AAC, FLAC, M4A, WMA, ALAC
Connections	1x Network (RJ45 Socket) 1x USB (for service) 4x Speaker Stereo (4-Pin connector) 1x USB-C trivum AudioBus Input (SDAT/MDAT) 1x USB-C trivum AudioBus Output (MDAT) 1x Power (cloverleaf socket)
Amplifier	Class D, 8x 30W @ 4 Ohm
Power Supply	AC 100V-240V (max. 200 watts) Idle power consumption (without active zone): 5 watts
Casing	Black lacquered steel sheet, 218 mm x 70 mm x 254 mm (WxHxD)
Weight (netto)	2,4 kg

1. Connection

- 1 Connect cables to audio speakers, ethernet network and power supply.

2. Configuration

The trivum SC340m can be configured via web browser.


We also recommend you to use the trivum Apps or trivum ServerAdmin Tool. The trivum Apps or ServerAdmin Tool will scan and list all trivum devices and their IP addresses in your network.

Using trivum App (iOS or Android)


- 2.1 Please scan QR Code to download the trivum iOS App or Android App. You can also visit -> <https://trivum.de/apps>



- 2.2 Start the App and tap on the button "Select trivum system".



Then all trivum devices in your network, their IP addresses and serial numbers will be listed..



Using trivum ServerAdminTool (Windows)

- 2.3 Please download and install the ServerAdmin Tool. -> <https://trivum.de/admin-tool>
- 2.4 Start the ServerAdmin Tool.
- 2.5 Double-click on the device (SC340m) to open the Music Center WebConfig (main config site).

i Note: If you are not sure about the assignment of the listed devices, you can compare the serial number in the list with the serial number on your device.

- 2.6 If you need static IP instead of DHCP: click "Network".
- 2.7 Select "Use static IP address".
- 2.8 Enter your IP settings and Restart to apply changes.

3. Adding a network share

The trivum SC340m can play audio files which are stored on network shares. If you want to use a shared directory, make sure that it supports the media sharing service Samba service (smb). To add a network share (e.g. NAS):

- 3.1 Open the Music Center WebConfig.
- 3.2 Click: "Music on NAS -> Setup music library -> Add network share".

- 3.3 Set the network path and user/password if required.
- 3.4 Click "Save as new share".
- 3.5 Click "Refresh" your music index now.

4. Adding your Online streaming service account

- 4.1 Open the Music Center WebConfig.
- 4.2 Click "Streaming".
- 4.3 Click "Add Service".
- 4.4 Select your favorite service and enter your user account.
- 4.5 Click Create the streaming service given account.

i Note: trivum supports only paid accounts.

Tip: The SC344m is AirPlay ready, so it's easy to stream every kind of music to the specific zone (with Apple devices).

Backup your configuration

Once you have completed the setup, we recommend you to make a backup of your configuration:

- Open the Music Center WebConfig.
- Click "Backup/Restore -> Export/import configuration".
- Follow the instructions.

For easy operation of your SC344m, we recommend our trivum TouchPad.

How to use a trivum TouchPad?

- Make sure your TouchPad is running software v2.35 or later.
- Wait a few seconds until the TouchPad has booted.
- On the starting screen press "Pair TouchPad with Audio System".
- Press "Select..." and select your preferred trivum MusicCenter from the pop-up menu.

How to use KNX?

The KNX programming of SC344m is done via the web browser. No need for extra KNX software.

- Open the Music Center WebConfig.
- Click "KNX->Setup KNX communication" and enable "use KNX / IP".
- Follow the instructions.

You find further informations for KNX on:

<https://trivum.de/knx-setup>

Further documentation and troubleshooting

To find helpful log files in support cases:

- Open the Music Center WebConfig.
- Click "Logs & Warnings".

Please visit also our website for the latest documentation, videos and information:

<https://www.trivum.com>
<https://service.trivum.com>

If support is needed

Please contact your local trivum dealer or write to:

service@trivum.com

Download links:

trivum ServerAdmin Tool (Windows):
<https://trivum.de/admin-tool>

trivum Apps (iOS, Android, Web):
<https://trivum.de/apps>

trivum technologies GmbH
Eierstraße 48
70199 Stuttgart
info@trivum.de
www.trivum.com

